




INDITION COMMERCE

Register Computer & Tablet

Prepare the computer or tablet that runs your Indition POS register.

Point of Sale Hardware · Setup Guide · June 2026

 © 2026 Indition Corp. All rights reserved. Indition™ and the Indition logo are trademarks of Indition Corp. All other product names, logos, and brands are the property of their respective owners.

What you need

The Indition POS register runs in a web browser at **/pos/**. Any modern computer, Mac, or tablet with an up-to-date browser will run it. A USB barcode scanner is strongly recommended.

1. Set up the browser

- 1 Use a current version of **Chrome, Edge, Safari, or Firefox**.
- 2 Run the browser **full-screen / kiosk mode** for a clean, distraction-free register.
- 3 Bookmark your register address (it ends in **/pos/**) so staff can open it in one tap.

2. Sign in

- 1 Cashiers sign in with the same email and password they use for the Indition back office.
- 2 On a trusted, staff-only register, tick **"Keep me signed in on this terminal"** so they don't re-type the password each time.

3. Connect your peripherals

- **Barcode scanner** — plug in the USB scanner (see the *Barcode Scanner* guide).
- **Receipt printer & cash drawer** — see the *Receipt Printer & Cash Drawer* guide.
- **Card reader** — see the *Stripe Reader S700 & S710 or WisePOS E & Stripe M2* guide.

4. Check the network

- The register needs to reach your Indition site, and the card reader needs to reach the internet. Keep both online.
- If the register briefly loses its connection during a card sale, the sale finishes automatically once it reconnects — nothing is lost.

5. Comfort & accessibility

- Use the **text-size** buttons (A / A / A) and the **light/dark** toggle in the top bar — each register remembers its own choice.

- Turn off the device's screen-saver / sleep during opening hours so the register stays ready.

One device, one cashier at a time: each cashier signs in, opens their shift, and signs out (or hands over with a shift close) so sales and the cash drawer stay tied to the right person.

Need help?

Email support@indition.com with your store name, the device you are setting up, and a photo of any error on screen. We usually reply within one business hour.

Indition Point of Sale — Register Computer & Tablet (Setup Guide) · June 2026
© 2026 Indition Corp. Need help? support@indition.com