




INDITION COMMERCE

Stripe Reader S700 & S710

Connect your card reader to Indition POS and take your first payment.

Point of Sale Hardware · Setup Guide · June 2026

 © 2026 Indition Corp. All rights reserved. Indition™ and the Indition logo are trademarks of Indition Corp. All other product names, logos, and brands are the property of their respective owners.

Before you start (about 10 minutes)

This guide connects a **Stripe Reader S700** or **S710** to your Indition POS register. Both models set up exactly the same way. You will need:

- The reader and the power cable that came in the box
- Your store's Wi-Fi network name and password
- An Indition admin login with **Manager** access or higher
- The web browser you normally use for the back office

1. Turn on the reader

- 1 Plug the USB-C cable into the **left side** of the reader, into the included power brick, and into a wall outlet.
- 2 Hold the **power button** on the right edge until the screen lights up (the first start takes about 30 seconds).
- 3 You will see a startup screen, then a status bar across the top.

2. Connect the reader to Wi-Fi

- 1 **Swipe in from the left edge** of the screen and tap **Settings**.
- 2 When asked for the admin passcode, enter .
- 3 Tap **Wi-Fi**, choose your store network, and enter the password.
- 4 Wait until the top status bar shows a Wi-Fi icon and the word **Online**. Stay on this screen for the next step.

Avoid guest Wi-Fi: networks with a sign-in page (hotel/guest/conference Wi-Fi) block the reader. Use the store's main network.

3. Generate a pairing code

The pairing code is three words that prove this reader is yours. It expires after about **30 seconds**, so be ready to do the next step right away.

- 1 Still in **Settings**, tap **Generate pairing code**.
- 2 Three words appear (for example `apple-pear-mango`). Note them down.

4. Add the reader in Indition

- 1 On your computer, sign in to the Indition admin and go to **POS → Card Readers → + Add new**.
- 2 **Store / dealer** — choose the store this reader lives at.
- 3 **Reader name** — something you will recognise in a list (e.g. "Front counter S700").
- 4 **Pairing code** — type the three words exactly (the order matters; capitals do not).
- 5 Tick **Set as default reader** if this is the store's only or main reader, then click **Save**.
- 6 After a moment the reader shows a green **Active** badge, and the reader screen switches to a "Ready" view.

5. Run a test sale

- 1 Sign in to **/pos/** at your register and add any **\$1 item** to the cart.
- 2 Click **Card → Charge**. The screen shows "Sending to reader..." then "Follow prompts on reader...".
- 3 On the reader, **insert, tap, or swipe** a card you can refund yourself.
- 4 When the reader says **Approved**, the receipt screen appears and the sale is done.
- 5 To tidy up, open the sale under **POS → Recent Sales** and click **Refund**.

You are ready to take live payments.

Troubleshooting

Problem	What to do
Never shows "Online"	Check the store Wi-Fi reaches where the reader sits; power-cycle the reader if it stays on "Connecting". Avoid guest Wi-Fi.
"Pairing code expired" when you Save	The code lasts about 30 seconds. Tap Generate pairing code again and save right away.
Active in admin but the register can't reach it	Reload <code>/pos/</code> . Confirm the reader is ticked as default under POS → Card Readers.
Reader says "No Location" / "Setup incomplete"	Your store record is missing its Stripe Terminal Location. Contact Indition support — this is a one-time setting on our side.
Sale finishes on the reader but the register doesn't move on	Check the register's internet. The pending sale resolves as soon as it reconnects — nothing is lost.
Screen goes dark	The reader sleeps after a few idle minutes. A short press of the power button wakes it; it reconnects to Wi-Fi automatically.

Need help?

Email support@indition.com with your store name, the device you are setting up, and a photo of any error on screen. We usually reply within one business hour.

Indition Point of Sale — Stripe Reader S700 & S710 (Setup Guide) · June 2026

© 2026 Indition Corp. Need help? support@indition.com